



## ECU Simos 10.11 - TC1766 Internal Flash

\*

Porre la centralina in Boot Mode, quindi connettere il seguente pinout e saldare le resistenze come in figura.

Utilizzare il driver:

**BOOT MODE TRICORE SAK TC1766**

Set in Boot Mode the ECU, so connect the following pinout and solder the the resistores like in the figure.

Use the driver:

**BOOT MODE TRICORE SAK TC1766**

