

HYUNDAI - KIA

BOSCH KME1.9.3 (GPL)



DRIVER: Tool Boot → Bench mode → Infineon
Tricore Benchmode → Tricore Sak TC1796
MICRO: TC1796

INFO

(EN) Set the tool as shown in the photo and connect the following pinout with the Tricore Cable.

(IT) Impostare lo strumento come indicato in foto e collegare il seguente pinout con il cavo Tricore.

RED: + 12V | BLACK: GROUND | BLUE: CAN-H | ORANGE : CAN-L | WHITE | BROWN

