

ALFA ROMEO

MARELLI MM10JA (Gasoline)



DRIVER: Tool Boot → Bench Mode → Motorola Freescale MPC5xx Benchmode → SPC5777 MM10JA
MICRO: SPC5777C + Int/Ext Eeprom

INFO

(EN) Set the tool as shown in the photo and connect the following pinout with the Tricore Cable.

(IT) Impostare lo strumento come indicato in foto e collegare il seguente pinout con il cavo Tricore.

RED: + 12V | **BLACK: GROUND** | **BLUE: CAN-H** | **ORANGE : CAN-L**

(EN) This Ecu has two CAN lines, therefore it is necessary to split them and connect them on the plug to communicate in Bench.

(IT) Questa Ecu ha due linee CAN, pertanto è necessario sdoppiarle e collegarle sulla spina per comunicare in Bench.

