

ECU SIEMENS LAND ROVER

SID203



DRIVER: Bdm/Jtag mode → Bdm MPC → MPC55x/56x

MICRO: MPC55x/56x

INFO

(EN) Connect the following pinout with the Tricore Cable.


(IT) Collegare il seguente pinout con il cavo Tricore.



(EN) Material required:

(IT) Materiale necessario:

Siemens Marelli
BDM Adapter tight



Gray flat cable



Pin strip



(EN) Do a link and solder the pin strip connectors on the bdm port. Connect the BDM adapter in the correct toward respecting pin 1.

(IT) Effettuare un ponte sulla scheda e saldare i connettori pin strip sulla porta bdm della scheda. Connettere l'adattatore BDM nel corretto verso rispettando il pin 1:

