



ECU MED17.0.7 - TC1782 Internal Flash

FASE 1: (LETTURA/SCRITTURA IN BOOT MODE)

Porre la centralina in Boot Mode, quindi connettere il seguente pinout e saldare le due resistenze da 1000Ohm e una da 100Ohm come in figura.

Utilizzare il driver:

BOOT MODE TRICORE SAK TC1782

STEP1: (READ/WRITE IN BOOT MODE)

Set in Boot Mode the ECU, so connect the following pinout and solder the two resistors of 1000Ohm and one of 100Ohm as in the figure.

Use the driver:

BOOT MODE TRICORE SAK TC1782

