

VAG GROUP

CONTINENTAL SIMOS 8.10 (Gasoline)



DRIVER: Tool Boot mode → Infineon Tricore Boot →
Tricore Sak TC1796
MICRO: TC1796 Internal Flash

INFO

(EN) Connect the following pinout with the Tricore Cable and put the Ecu in Bootmode.

(IT) Collegare il seguente pinout con il cavo Tricore e mettere l'ecu in Bootmode.

RED: + 12V | BLACK: GROUND | BLUE: CAN-H | ORANGE : CAN-L



(EN) Connect the 1000 and 560 Ohm resistors on the Ecu card as pictured.

(IT) Collegare le resistenze da 1000 e 560 Ohm sulla scheda della Ecu come in foto.

