



ECU Siemens Continental SID309 - TC1767 Internal Flash



FASE 1:

Per trovare la password bisogna connettere lo strumento sulla macchina tramite la presa OBD e lanciare il driver:

OBD TOOL PASSWORD SID309

RENAULT – NISSAN – MERCEDES

Successivamente sarà possibile smontare la centralina dalla macchina e porla in Boot mode come alla seguente fase 2.

(**Attenzione:** Se non viene trovata la password sulla macchina bisogna provare a banco connettendo il pinout.)

STEP 1:

To find the password you must to connect the tool by OBD plug on the car and use the driver:

OBD TOOL PASSWORD SID309

RENAULT – NISSAN – MERCEDES

After that, you will disassemble the car's control unit and set it in Boot mode like in next step 2.

(**Attention:** if it don't find password on the car you must try on the table connecting the pinout.)

FASE 2:

Porre la centralina in Boot mode, quindi connettere il seguente pinout e saldare le resistenze come nella figura. Utilizzare il driver:


BOOT MODE TRICORE SAK TC1767

STEP 2:

Set in Boot mode the ECU, so connect the following pinout and solder the resistances like shown in the figure below.

Use the driver:

BOOT MODE TRICORE SAK TC1767



BOOTMODE:

