



ECU EMS SDI 3 - TC1796 Internal-External Flash

FASE 1: (LETTURA/SCRITTURA IN BOOT MODE)

Porre la centralina in Boot Mode, quindi connettere il seguente pinout e saldare le due resistenze e il link come in figura. Utilizzare il driver:

BOOT MODE TRICORE SAK TC1796

STEP1: (READ/WRITE IN BOOT MODE)

Set in Boot Mode the ECU, so connect the following pinout and solder the two resistore and the link like in the figure.

Use the driver:

BOOT MODE TRICORE SAK TC1796

