



ECU Siemens Continental SID209 - TC1797 Internal Flash

FASE 1: (TROVARE PASSWORD)

Per trovare la password bisogna connettere lo strumento sulla macchina tramite la presa OBD e lanciare il driver:

OBD TOOL PASSWORD SID209 FORD

Successivamente sarà possibile smontare la centralina dalla macchina e porla in Boot mode come alla seguente fase 2.

(**Attenzione:** Se non viene trovata la password sulla macchina bisogna provare a banco connettendo solo il pinout.)

STEP 1: (FIND PASSWORD)

To find the password you must to connect the tool by OBD plug on the car and use the driver:

OBD TOOL PASSWORD SID209 FORD

After that, you will disassemble the car's control unit and set it in Boot mode like in next step 2.

(**Attention:** if it don't find password on the car you must try on the table connecting only the pinout.)

FASE 2: (LEGGERE/SCRIVERE IN BOOT MODE)

Porre la centralina in Boot mode, quindi connettere il seguente pinout e saldare le resistenze come nella figura.

Utilizzare il driver:

BOOT MODE TRICORE SAK TC1797

STEP 2: (READ/WRITE IN BOOT MODE)

Set in Boot mode the ECU, so connect the following pinout and solder the resistances like shown in the figure below.

Use the driver:

BOOT MODE TRICORE SAK TC1797

