



The lay-by pins are placed in the lower part of the ECU.




CONNECTIONS



DIRECT CONNECTION


Connect the universal connector F34TD003 to POL4 & POL5 and to the ECU connector as shown in the pictures.



F34TD003
ADATTATORE UNIVERSALE K, CAN, BDM
UNIVERSAL ADAPTER K, CAN, BDM

BOOT MODE K-CAN MICRO ST10F2XX & TRICORE

COLOR / COLORE	SIGNAL / SEGNALE
YELLOW / GIALLO	K-LINE
GREEN / VERDE	CAN LOW
WHITE / BIANCO	CAN HIGH
BLUE / BLU	POL 5
GREY / GRIGIO	POL4
BROWN / MARRONE	RESET



BDM MODE MICRO MOTOROLA MPC5xx

COLOR / COLORE	SIGNAL / SEGNALE
YELLOW / GIALLO	DSD0
GREEN / VERDE	DSDI
BROWN / MARRONE	RESB
GREY / GRIGIO	DSCK

