






PLUGIN 198 EDC17C10 XROM TC1796

DIRECT CONNECTION

DIMA CONNECTION


Connect the boot pin to the programming layby pin n. 10



F34TD003 UNIVERSAL ADAPTER K, CAN, BDM

BOOT MODE K-CAN MICRO ST10F2XX & TRICORE

COLOR / COLORE	SIGNAL / SEGNALE
YELLOW / GIALLO	K-LINE
GREEN / VERDE	CAN LOW
WHITE / BIANCO	CAN HIGH
BLUE / BLU	POL 5
GREY / GRIGIO	POL4
BROWN / MARRONE	RESET



BDM MODE MICRO MOTOROLA MPC5xx

COLOR / COLORE	SIGNAL / SEGNALE
YELLOW / GIALLO	DSD0
GREEN / VERDE	DSDI
BROWN / MARRONE	RESB
GREY / GRIGIO	DSCK

