



**PLUGIN 170 : maps located in the EXTERNAL FLASH**

**DIRECT CONNECTION**

**DIMA CONNECTION**

Connect the BOOT pin to the N 10 PAD of the lay-by pins.

