

PSA GROUP SIEMENS SID208 (Diesel)



DRIVER: Tool Boot mode → Infineon Tricore
Benchmode Simos Sim → Benchmode SID208 - PSA
Tricore Sak TC1797
MICRO: TC1797

INFO

(EN) Set the tool as shown in the photo and connect the following pinout with the Tricore Cable.

(IT) Impostare lo strumento come indicato in foto e collegare il seguente pinout con il cavo Tricore.

RED: + 12V | **BLACK: GROUND** | **BLUE: CAN-H** | **ORANGE : CAN-L**



(EN) It will now be possible to read and write the ECU.

(IT) Ora sarà possibile leggere e scrivere la ECU.