

The lay-by pins are placed in the lower-right part of the ECU, as shown in the picture.




DIRECT CONNECTION with DELPHI F34FL003

Connect the power +12V (black wire of the kit F34FL003) as in the picture to pin n.4 of the connector.



Connect the adapter F34FL003 as shown in the picture.



DIMA CONNECTION

Use the DIMA adaptor F34DM001, connect just one of the two red cables (+12V) to the PIN4 as in the following pictures.

