


PLUGIN 553, 554 :NEW TRASDATA

Warning: this ECU contains 2 different microprocessors, verify the specific connections for each microprocessor: micro 01 plugin 553 and micro 02 plugin 554.






ECU DIRECT CONNECTION for READING & WRITING: MICRO 01 Plugin 553

In order to connect to the ECU use the F34NTA13 wiring
Make sure that the POWER led (red) on NEW TRASDATA is ON.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION	
MARRONE BROWN	BOOT	
BLU BLUE	CNF	
NERO BLACK	GIALLO YELLOW	
GRIGIO GREY	VERDE GREEN	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
NERO BLACK	MASSA GND	



ECU DIRECT CONNECTION for READING & WRITING: MICRO 02 Plugin 554

In order to connect to the ECU use the F34NTA13 wiring
Make sure that the POWER led (red) on NEW TRASDATA is ON.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION	
MARRONE BROWN	BOOT	
BLU BLUE	CNF	
NERO BLACK	GIALLO YELLOW	
GRIGIO GREY	VERDE GREEN	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
NERO BLACK	MASSA GND	

