

PCMflash

Engine Control Unit

ME17.8.8/ME17.8.8.1/ME17U6 TC1728/TC1782

Connection version 1



+12V	T1: 20, 35	CAN-L	T1: 17
GND	T1: 64	CAN-H	T1: 1
GPT*	T2: 93, 96		

*Select "Use other GPT output pins" in the pcmflash settings or set GPT to EXT in case powerbox for PCMflash is used /
 При использовании powerbox for PCMflash выбрать режим GPT EXT или использовать альтернативные пины

Connection version 2



+12V	T1: 20, 35	CAN-L	T1: 3
GND	T1: 64	CAN-H	T1: 4
GPT*	T2: 93, 96		

*Select "Use other GPT output pins" in the pcmflash settings or set GPT to EXT in case powerbox for PCMflash is used /
 При использовании powerbox for PCMflash выбрать режим GPT EXT или использовать альтернативные пины

CHINA

pcmflash.ru

v.1

2023-07-01