

FCA GROUP

BOSCH EDC16C39 (Diesel)



DRIVER: Tool Boot mode → Motorola Freescale MPC5xx Benchmode → EDC16/ME9 - MPC56x
MICRO: MPC562

INFO

(EN) Set the tool as shown in the photo and connect the following pinout with the Tricore Cable.

(IT) Impostare lo strumento come indicato in foto e collegare il seguente pinout con il cavo Tricore.

RED: + 12V | **BLACK: GROUND** | **GREEN: K-LINE** | **WHITE** | **BROWN**


HARDWARE 1



HARDWARE 2



HARDWARE 3



(EN) Power the benchplus + with a **voltage from 9 to 10 Volts** for EDC16 / MED9 control units.

(IT) Alimentare il benchplus+ con una **tensione da 9 a 10 Volt** per centraline EDC16/MED9.