

CONTROL UNIT AUTO5

Utilizzare il cavo Renesas per alimentare la centralina tramite il pinout.

Sulla scheda effettuare 3 link e connettere i fili bianco e viola del cavo Renesas.

Use the Renesas cable to give power at the control unit from the pinout.

On the card, do 3 links and connect the white and violet wires of the Renesas cable.

