

IVECO

BOSCH EDC17C69 (Diesel)




DRIVER: Tool Boot mode → Infineon Tricore
Benchmode → Tricore Sak TC1793
MICRO: TC1793

INFO

(EN) Set the tool as shown in the photo and connect the following pinout with the Tricore Cable.

(IT) Impostare lo strumento come indicato in foto e collegare il seguente pinout con il cavo Tricore.

RED: + 12V | BLACK: GROUND | BLUE: CAN-H | ORANGE : CAN-L | WHITE | BROWN



(EN) There may not be frequencies on this control unit, so you will need to open it and read it in **bootmode tricore**.

(IT) Su questa centralina è possibile che non siano presenti le frequenze, quindi sarà necessario aprirla e leggerla in **bootmode tricore**.