

OPEL - GM

DELCO E80 (Gasoline)




DRIVER: Bench Mode → Motorola Freescale MPC5xx Benchmode → MPC5676 DELCO E80
MICRO: MPC5676 + Int.Eeprom

INFO

(EN) Set the tool as shown in the photo and connect the following pinout with the Tricore Cable.

(IT) Impostare lo strumento come indicato in foto e collegare il seguente pinout con il cavo Tricore.

RED: + 12V | BLACK: GROUND | BLUE: CAN-H | ORANGE : CAN-L



(EN) Please read the ecu data carefully and do not modify the areas indicated, otherwise the ecu may be damaged.

(IT) Si prega di leggere attentamente i dati ecu e di non modificare le zone indicate, in caso contrario la ecu potrebbe danneggiarsi.