

FORD

BOSCH EDC17C10 (Diesel)



DRIVER: Tool Boot mode → Infineon Tricore
 Benchmode → Tricore Sak TC1796/ TC1797
 MICRO: TC1796 / TC1797

INFO

(EN) Set the tool as shown in the photo and connect the following pinout with the Tricore Cable.

(IT) Impostare lo strumento come indicato in foto e collegare il seguente pinout con il cavo Tricore.

RED: + 12V | BLACK: GROUND | BLUE: CAN-H | ORANGE : CAN-L | WHITE | BROWN

PINOUT TYPE 1 (WIDE CONNECTOR)



PINOUT TYPE 2 (NARROW CONNECTOR)



(EN) This ecu has two hardware versions:
 one with Tricore Sak TC1796 + Ext. Flash;
 one with Tricore Sak TC1797;
 try both drivers in case of failure to recognize the ecu.

(IT) Questa ecu ha due versioni hardware:
 una con Tricore Sak TC1796 + Ext. Flash;
 una con Tricore Sak TC1797;
 provare entrambi i driver nel caso del mancato riconoscimento della ecu.