

OPEL

BOSCH EDC17C84 (Diesel)



DRIVER: Tool Boot mode → Infineon Tricore
 Benchmode → Tricore Sak TC1782
 MICRO: TC1782


INFO

(EN) Set the tool as shown in the photo and connect the following pinout with the Tricore Cable.


(IT) Impostare lo strumento come indicato in foto e collegare il seguente pinout con il cavo Tricore.

RED: + 12V | BLACK: GROUND | BLUE: CAN-H | ORANGE : CAN-L | WHITE | BROWN

HARDWARE 1



HARDWARE 2



(EN) On some vehicles reading in Benchmode is not available, so you will have to proceed in **Boot Mode**.

(IT) Su alcuni veicoli non è disponibile la lettura in Benchmode, quindi si dovrà procedere in **Boot Mode**.