




Mercedes-Benz

ECU CRD: 3.1R, 3.2R, 3.30, 3.58, 3.59, 3.60 , 3.7A, 3P.A0, 3.N5
SOLENOID - TC1797 Internal Flash



Per comunicare con la centralina usando il driver OBD
(no bootmode) connettere il pinout nel seguente modo:

*For communicate with the ECU using OBD driver
(no bootmode) connect the pinout in the next
method:*

+12V: Pin 5,15 GND: Pin 2 CAN H: 41 CAN L: 54

