

BMW, MINI

BOSCH MEV17.2.1 (Gasoline)




DRIVER: Tool Boot mode → Infineon Tricore
 Benchmode → Tricore Sak TC1796
 MICRO: TC1796

INFO

(EN) Set the tool as shown in the photo and connect the following pinout with the Tricore Cable.

(IT) Impostare lo strumento come indicato in foto e collegare il seguente pinout con il cavo Tricore.

RED: + 12V | BLACK: GROUND | BLUE: CAN-H | ORANGE : CAN-L | WHITE | BROWN



(EN) If using the **BENCH MODE TRICORE SAK TC1796** driver, the external Flash is recognized, use the driver: **BENCHMODE TRICORE SAK TC1796 + Ext. FLASH**

(IT) Se utilizzando il driver **BENCH MODE TRICORE SAK TC1796**, viene riconosciuta la Flash esterna, utilizzare il driver: **BENCHMODE TRICORE TRICORE SAK TC1796 + Ext. FLASH**