


LAND ROVER BOSCH MEDC17.9 (Diesel)



RED: + 12V | BLACK: GROUND | BLUE: CAN-H | ORANGE : CAN-L



Leggere e scrivere la centralina a banco connettendo il pinout poiché sulla vettura è presente un timeout che dopo alcuni minuti spegne il quadro e interrompe il dialogo con la centralina.

Read and write the ECU on table by connecting the pinout because there is a timeout that switch off the dashboard and that interrupts the communication after a few minutes.

Al termine della lettura il software salverà nella stessa directory anche un file chiamato **TriPSW.bin** nel quale è presente la password per poter eventualmente leggere e scrivere la centralina in boot mode tricore. Se si vuole quindi operare in boot mode tricore copiare prima questo file TriPSW.bin nella cartella in cui è installato il programma. Non sarà quindi necessario utilizzare il driver "tool password special all" per ricercare la password.

At the end of the reading, the software will save in the same directory a file called **TriPSW.bin** that as the password inside for reading and writing eventually the ECU in boot mode tricore. If you want to operate in boot mode first copy this TriPSW.bin file in the folder where the program is installed. Therefore, it will not be necessary to use the driver "tool password special all" to search the password.