

Caterpillar ADEM 4 COMMON RAIL

Kit da utilizzare:

- Cavo multifunzione
- Adattatore Delphi
- Cavetto flat grigio
- Connettori dip/sip
- Connettore verde jack per alimentazione esterna

Kit to use:



- Multifunction cable
- Delphi adapter
- Grey flat cable
- Connectors dip/sip
- Green jack connector for external supply power

Collegare il cavo multifunzione nel seguente modo e saldare i connettori dip/sip sulla scheda.

Questa centralina necessita di un alto amperaggio. Quindi raccomandiamo di alimentare il sistema collegando una batteria esterna tramite il connettore jack verde al tool.


Connect multifunction cable as follows and solder the dip/sip connectors on the pcb.

This control unit requires a high amperage. So we recommend powering the system by connecting an external battery via the green jack connector to the tool.




Saldare i connettori dip/sip sulla scheda:

Solder the dip/sip connectors on the pcb:



Inserire l'adattatore Delphi come in foto:

Insert Delphi adapter as in photo:



Per leggere e scrivere utilizzare il seguente driver:

- BDM / JTAG MODE
- BDM MPC
- **MPC 55x/56x**

To read and write use the following driver:

- BDM/ JTAG MODE
- BDM MPC
- **MPC55x/56x**