


BOSCH EDC17 CP52 [1797] – Iveco [Diesel]

Collegare il cavo multifunzione nel seguente modo:


Connect the multifunction cable as follows:

RED: + 12V	5, 82
BLACK: GROUND	2, 7
BLUE: CAN-H	62
ORANGE: CAN-L	61
WHITE	22 or 24
BROWN	53



Attenzione: Alcune centraline entrano in bench mode con il seguente pinout. Quindi se non comunica in bench connettere come segue:

Attention: Some controllers enter bench mode with the following pinout. Therefore, if it does not communicate in bench mode, connect as follows:



Per leggere e scrivere utilizzare il seguente driver:
→ BENCH TRICORE
→ IVECO
→ TC1797 – IVECO
→ EDC17 CP52

To read and write use the following driver:
→ BENCH TRICORE
→ IVECO
→ TC1797 - IVECO
→ EDC17 CP52