

MERCEDES TRUCK CONTINENTAL / TEMIC (Diesel)



On the table:

- Do connections like shown following
- Give power using a battery or power supply +24V
- The tool EOBD2 must be always powered +24V
- Start the software EOBD2.exe and select driver:
MERCEDES TRUCK > (model) > E3/E4/E5 ECU TEMIC EOBD
- Close main switch power
- Close key switch ignition
- When the software alert: open / close only the key switch ignition.

On the truck:

- Connect on plug the tool like descript on the manual Plug Diagnose
- Start the software EOBD2.exe and select the OBD driver
- Follow the messages of the software.

A banco:

- Effettuare le connessioni come indicato in basso
- Alimentare usando una batteria o alimentatore + 24V
- Lo strumento deve rimanere sempre alimentato +24V
- Avviare il software EOBD2.exe e selezionare il driver:
MERCEDES TRUCK > (model) > E3/E4/E5 ECU TEMIC EOBD
- Chiudere l'interruttore principale (main switch power)
- Chiudere l'interruttore del quadro (switch ignition)
- Quando il software avvisa: aprire / chiudere solo l'interruttore del quadro (switch ignition)

Sul camion:

- Connettere il tool alla presa del camion come descritto nel manuale Plug Diagnose
- Avviare il software EOBD2.exe e selezionare il driver
- Seguire i messaggi del software.

