




Per connettersi alla centralina utilizzare:

- Cavo multifunzione
- Connettori pin rotondi

To connect to the control unit use:

- Multifunction cable
- Round Pin connectors

|                      |              |
|----------------------|--------------|
| <b>RED: + 12V</b>    | <b>6, 11</b> |
| <b>BLACK: GROUND</b> | <b>19</b>    |
| <b>BLUE: CAN-H</b>   | <b>5</b>     |
| <b>ORANGE: CAN-L</b> | <b>2</b>     |

