

MERCEDES BENZ

DELPHI CRD3.xx - CRD3P.xx (Diesel)



DRIVER: Tool Boot mode → Bench CRD3.X
 Mercedes Tricore TC1793/97 → TC1793 - TC1797
MICRO: TC1793 - TC1797

INFO

(EN) Set the tool as shown in the photo and connect the following pinout with the Tricore Cable.

(IT) Impostare lo strumento come indicato in foto e collegare il seguente pinout con il cavo Tricore.

RED: + 12V | **BLACK: GROUND** | **BLUE: CAN-H** | **ORANGE : CAN-L**

(EN) With this driver you can read and write all mercedes CRD3 - CRD3P ecus including all possible versions (e.g. CRD3.50 - CRD3P.E1).
 It is also possible to carry out benchmode clones on ecus without OTP Area.

(IT) Con questo driver è possibile leggere e scrivere tutte le ecu Mercedes CRD3 - CRD3P comprese tutte le eventuali versioni (es. CRD3.50 - CRD3P.E1).
 E' inoltre possibile effettuarsi cloni in benchmode su ecu senza OTP Area.

