

FORD

VISTEON DCU-204 (Diesel)




DRIVER: Tool Boot mode → ST10Fxxx
Driver K-line: ST10F273/5/6 BOOT MODE
Driver CAN: ST10F273/5/6 BOOT MODE *CAN
MICRO: ST10F276

INFO

(EN) Connect the following pinout with the Tricore Cable and put the Ecu in Bootmode.

(IT) Collegare il seguente pinout con il cavo Tricore e mettere l'ecu in Bootmode.

RED: + 12V | **BLACK: GROUND** | **GREEN: K-LINE** | **BLUE: CAN-H** | **BLUE: CAN-L**



(EN) On next page another boot modality using Rx and Tx - required firmware since version 2012.

(IT) A pagina successiva un'altra modalità di boot usando Rx e Tx - richiesto firmware da versione 2012.



DRIVER: Tool Boot mode → ST10Fxxx → ST10F273/5/6 BOOT MODE *Rx Tx
MICRO: ST10F276

INFO

(EN) Connect the following pinout with the Tricore Cable and put the Ecu in Bootmode.

(IT) Collegare il seguente pinout con il cavo Tricore e mettere l'ecu in Bootmode.

RED: + 12V | BLACK: GROUND

