

**NEW TRASDATA**  
PLUGIN 927 - 1105



**ECU 001**




## DIRECT CONNECTION


In order to connect to the ECU use the CABLE F32GN037C.

Make sure that the POWER led (red) on NEW TRASDATA is ON.

| COLORE FILO<br>WIRE COLOUR  | DESCRIZIONE<br>DESCRIPTION               |
|-----------------------------|------------------------------------------|
| ROSSO<br>RED                | POSITIVO DIRETTO<br>POWER BATTERY        |
| ARANCIO<br>ORANGE           | POSITIVO SOTTO QUADRO<br>POWER SWITCH ON |
| NERO<br>BLACK               | MASSA<br>GND                             |
| GIALLO<br>YELLOW            | KLINE                                    |
| VERDE<br>GREEN              | CAN LOW                                  |
| BIANCO<br>WHITE             | CAN HIGH                                 |
| GRIGIO<br>GREY              | POL4<br>BOOT                             |
| BLU<br>BLUE                 | POL5<br>CNF1                             |
| VIOLA/GRIGIO<br>PURPLE/GREY | TENSIONE PROG.<br>PROG. VOLTAGE          |
| MARRONE<br>BROWN            | RESET                                    |



## CONNECTOR ECU 001 & ECU 002



## BOOT DIRECT CONNECTION


Connect the GREY wire of the cable F32GN037C as described here below :

| COLORE FILO<br>WIRE COULOR | DESCRIZIONE<br>DESCRIPTION |
|----------------------------|----------------------------|
| GRIGIO<br>GREY             | POL4<br>BOOT               |

## RX & TX & GND CONNECTION

For the RX & TX & GND lines it is necessary to use the flat cable F34NTF53.

| Pin | Colore<br>Colour      |
|-----|-----------------------|
| 11  | Non usato<br>Not used |
| 12  | Non usato<br>Not used |
| 13  | Non usato<br>Not used |
| 14  | Non usato<br>Not used |
| 15  | Non usato<br>Not used |
| 16  | Non usato<br>Not used |
| 17  | Non usato<br>Not used |
| 18  | Non usato<br>Not used |
| 19  | Bianco<br>White       |
| 20  | Nero<br>Black         |
| 21  | Marrone<br>Brown      |
| 22  | Non usato<br>Not used |
| 23  | Non usato<br>Not used |
| 24  | Non usato<br>Not used |
| 25  | Non usato<br>Not used |
| 26  | Non usato<br>Not used |

**ECU 001**

**ECU 002**