




On this ECU it is possible only the DIRECT CONNECTION



DIRECT CONNECTION

WARNING: On F34TD003 adapter early versions the resistance R1 was not 000 (short circuit) but was 1001, so it is necessary to remove the resistance and make short circuit on these 2 soldering pads. This operation is not necessary if R1=000



To be able to read and write the memories it is necessary to short circuit the two lay-by pins shown in the picture with LINK 1 mark. At the end of the procedure remove the short circuit.

